



## Wax Filler Sticks

- Blended wax filler for repairing finished furniture
- Fills small to medium holes, cracks and scratches without sanding or having to strip the finish
- All colours are intermixable
- Easy to use
- Quick drying
- Wide range of colours available



### Product use

Liberon Wax Filler Sticks are available in a wide range of wood colours. The advantages of an application without a heat source and no shrinkage make them ideal for use on finished furniture and other articles.

### Application

Scrape off some shavings from the wax, enough to fill the hole, and soften with your fingers. Press into the crack or hole using a Liberon Plastic Scraper or other suitable tool. Level down with the scraper and buff off the excess with a cloth.

**Important:** Always test product on a spare surface or inconspicuous area for colour, compatibility and end result.

### Colours

White, Ebony, Ivory, Light Oak, Medium Oak, Dark Oak, Mahogany, Dark Mahogany, Light Pine, Pine, Rosewood, Light Walnut, Medium Walnut, Dark Walnut, Dark Yew, Teak.

### Packaging

Wax Filler Sticks are available in 50 g loose, 50 g BP and a box set of 16 x 50 g.